Experiment Three

Mathematical Modelling Using SimScape (Mechanical Systems)

Control Systems Laboratory Dr. Zaer Abo Hammour



1. <u>Translational Mechanical System</u>

In this example, you are going to model a simple mechanical system and observe its behavior under various conditions. This tutorial illustrates the essential steps to building a physical model and makes you familiar with using the basic Simscape blocks.

The figure 3.1 shows a simple model of a car suspension. It consists of a spring and damper connected to a body (represented as a mass), which is agitated by a force. You can vary the model parameters, such as the stiffness of the spring, the mass of the body, or the force profile, and view the resulting changes to the velocity and position of the body.



Figure 3.1: A model of Car Suspension

To create an equivalent Simscape diagram, follow these steps:

- 1. Open the Simulink® Library Browser, as described in Simscape Block Libraries.
- Create a new model. To do this, from the top menu bar of the Library Browser, select File > New > Model. The software creates an empty model in memory and displays it in a new model editor window.
- **3.** Open the **Simscape > Foundation Library > Mechanical > Translational Elements** library as shown in figure 3.2.
- **4.** Drag the Mass, Translational Spring, Translational Damper, and two Mechanical Translational Reference blocks into the model window.
- 5. Orient the blocks as shown in the figure 3.3. To rotate a block, select it and press Ctrl+R.
- **6.** Connect the Translational Spring, Translational Damper, and Mass blocks to one of the Mechanical Translational Reference blocks as shown in figure 3.4.



Figure 3.2: Mechanical Translational Elements, step 3



Figure 3.3: Selected Elements, step 5



Figure 3.4: Connect the elements to each other, step 6

 To add the representation of the force acting on the mass, open the Simscape > Foundation Library > Mechanical > Mechanical Sources library figure 3.5, and add the Ideal Force Source block to your diagram as figure 3.4.

	Simulink Library Browser					- U	×			
\Leftrightarrow	🗇 Enter search term 🗸 🔌	•	3 - 📼	-= (3					
Sin	Simscape/Foundation Library/Mechanical/Mechanical Sources									
⊳	Fuzzy Logic Toolbox	^	,		4	ا				
⊳	HDL Coder		<u>(</u> f	3		(A)				
⊳	HDL Verifier			e noular	Ideal Force Source, Ide					
	Image Acquisition Toolbox		Velocity	Source	Tucur orce source rue	ar forque source				
	Instrument Control Toolbox									
	Model Predictive Control Toolbox		Á	•						
	Neural Network Toolbox		2	2						
	OPC Toolbox		Ideal Tran	slationa						
	Phased Array System Toolbox		velocity	Source						
	Real-Time Windows Target									
	Report Generator									
	Robust Control Toolbox									
	SimEvents									
	Simerano									
-	A Foundation Library									
	 Flectrical 									
	 Electrical Hydraulic 									
	Magnetic									
	4 Mechanical									
	Mechanical Sensors									
	Mechanical Sources									
	Mechanisms									
	Rotational Elements									
	Translational Elements									
	Physical Signals									
	Pneumatic									
	Thermal									
	Thermal Liquid									
	SimDriveline									
	SimElectronics									
	SimHydraulics									
	SimMechanics	٧								

Figure 3.5: Mechanical Force, step 7



Figure 3.6: The block diagram after add the Force, step 7

8. Add the sensor to measure speed and position of the mass. Place the Ideal Translational Motion Sensor block from the **Mechanical Sensors library** figure 3.7 into your diagram and connect it as shown in figure 3.8.



Figure 3.7: Mechanical Sensors Library



Figure 3.8: Block Diagram

- 9. Now you need to add the sources and scopes. They are found in the regular Simulink libraries. Open the Simulink > Sources library and copy the Signal Builder block into the model. Then open the Simulink > Sinks library and copy two Scope blocks. Rename one of the Scope blocks to *Velocity* and the other to *Position*.
- 10. Every time you connect a Simulink source or scope to a Simscape diagram, you have to use an appropriate converter block, to convert Simulink signals into physical signals and vice versa. Open the Simscape > Utilities library figure 3.9 and copy a Simulink-PS Converter block and two PS-Simulink Converter blocks into the model. Connect the blocks as shown in figure 3.9.
- 11. Each topologically distinct physical network in a diagram requires exactly one Solver Configuration block, found in the Simscape > Utilities library figure 3.9. Copy this block into your model and connect it to the circuit by creating a branching point and connecting it to the only port of the Solver Configuration block. Your diagram now should look like figure 3.10.







Figure 3.1: Block Diagram of System

• Modifying Initial Settings

After you have put together a block diagram of your model, as described in the previous section, you need to select a solver and provide the correct values for configuration parameters.

To prepare for simulating the model, follow these steps:

1. Select a Simulink solver. On the top menu bar of the model window, select Simulation > Model Configuration Parameters. The Configuration Parameters dialog box opens, showing the Solver node.

Under Solver options, set Solver to *ode23t (mod.stiff/Trapezoidal)* and Max step size to 0.2.

Also note that Simulation time is specified to be between 0 and 10 seconds. You can adjust this setting later, if needed.

Select:	Simulation time					
Solver Data Import/Export	Start time: 0.0		Stop time: 10.0	Stop time: 10.0		
Data Import/Export • Optimization • Diagnostics Hardware Implementation Model Referencing • Simulation Target • Code Generation Simscape SimMechanics 1G • SimMechanics 2G	Solver options Type: Max step size: Min step size: Initial step size: Solver reset method: Number of consecutiv Solver Jacobian meth Tasking and sample to Tasking mode for peri Automatically hand Higher priority valu	Solver options Type: Variable-step Max step size: 0.2 Min step size: auto Initial step size: auto Solver reset method: Fast Number of consecutive min steps: Solver Jacobian method: Tasking and sample time options Tasking mode for periodic sample times: Automatically handle rate transition for data transfer		ode23t (mod. stiff/Trapezoidal) 1e-3 auto : Disable All	•	
	Zero-crossing options			1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 - 1999 -		
	Zero-crossing control:	Use local settings	 Algorithm: 	Nonadaptive	•	
	Time tolerance:	10*128*eps	Signal threshold:	auto		
	Number of consecutiv	e zero crossings:		1000		

Figure 3.2: Solver Configuration

2. <u>Rotational Mechanical System</u>

In this example, you are going to model a mechanical system and observe its behavior under various conditions. This tutorial illustrates the essential steps to building a physical model and makes you familiar with using the basic Simscape blocks.

The figure 3.12 shows a rotational mechanical system. It consists of a spring and damper connected to a body (represented as a inertia), which is agitated by a torque. You can vary the model parameters, such as the stiffness of the spring, the inertial of the body, or the torque profile, and view the resulting changes to the angular velocity and angular position of the body.



Figure 3.12 A Rotational Mechanical System

• Modeling of System

To create an equivalent Simscape diagram, follow these steps:

- 12. Open the Simulink® Library Browser, as described in Simscape Block Libraries.
- 13. Create a new model. To do this, from the top menu bar of the Library Browser, select File > New > Model. The software creates an empty model in memory and displays it in a new model editor window.
- **14.** Open the **Simscape > Foundation Library > Mechanical > Rotaional Elements** library as shown in figure 3.13.
- **15.** Drag the Inertial, Rotational Spring, Rotational Damper, and Mechanical Rotaional Reference blocks into the model window.
- 16. Orient the blocks as shown in the figure 3.14. To rotate a block, select it and press Ctrl+R.
- **17.** Connect the Translational Spring, Translational Damper, and Mass blocks to one of the Mechanical Translational Reference blocks as shown in figure 3.15

	Simulink Library Browser				—	\times
4	Enter search term	~	A 🛃 - 🔚	+ 2		
Sir	nscape/Foundation Librar	y/I	lechanical/Rotatio	nal Elements		
	Embedded Coder Fuzzy Logic robbox HOL Coder HOL Verffer Tange Acquisition Toolbox Model Predictive Control Toolbox Neural Network Toolbox OPC Toolbox Phased Array System Toolbo Real-Time Windows Targot Report Generator Robust Control Toolbox SmRVents SmRVents SmRVents SmRVents Mechanical Sen Mechanical Sen Mechanical Sou Mechanical Sen Mechanical Sen Mechanical Sen Mechanical Sen Mechanical Sen Mechanical Sen Nethanist Physical Signals Physical Signals Physical Signals Physical Signals Physical Signals Physical Signals Physical Signals Simplyeraulics Simplyeraulics Simplyeraulics Simplyeraulics Simplyeraulics Simplyeraulics Simplyeraulics Simplyeraulics Simplyeraulics Simplyeraulics Methanics Simplyeraulics Simp		Inertia	Mechanical Mechanical Rotational Reference en Hes Rotational Friction	Rotational Hard Stop	







Figure 3.5: Connect the elements to each other, step 6

18. To add the representation of the force acting on the mass, open the Simscape > Foundation Library > Mechanical > Mechanical Sources library figure 3.16, and add the Ideal Torque Source block to your diagram as figure 3.17.

	Simulink Elbrary browser							
\Leftrightarrow	🖙 Enter search term 🗸 🔩		🖏 🕶 🔚	- (2			
Simscape/Foundation Library/Mechanical/Mechanical Sources								
	scape/Foundation Library/Mecha Fuzzy Logic Toolbox HDL Coder HDL Verifier Image Acquisition Toolbox Instrument Control Toolbox Model Predictive Control Toolbox Neural Network Toolbox OPC Toolbox Phased Array System Toolbox Real-Time Windows Target Report Generator Robust Control Toolbox SimEvents SimRe Simscape Foundation Library Electrical Hydraulic Magnetic Mechanical Sensors Mechanical	^	al/Mechani	gular j gular iource j alational ource	Ideal Force Source Ideal Torque Source			
	SimMechanics	¥						

Figure 3.6: Mechanical Force, step 7



Figure 3.17: The block diagram after add the Force, step 7

19. Add the sensor to measure angular speed and angular position at $\theta_2(t)$. Place the Ideal Rotaional Motion Sensor block from the **Mechanical Sensors library** figure 3.18 into your diagram and connect it as shown in figure 3.19.

Simulink Library Browser		— 🗆	×							
💠 🗇 Enter search term 🗸 🗛	• 🖏 • 🛅 😐 🔇									
Simscape/Foundation Library/Mechanical/Mechanical Sensors										
 Fuzzy Logic Toolbox HDL Coder HDL Coder HDL Verifier Image Acquisition Toolbox Instrument Control Toolbox Model Predictive Control Toolbox Pervel Network Toolbox OPC Toolbox Phased Array System Toolbox SimRer Simscape Foundation Library Electrical Hydraulic Mechanical Sensors Mechanical Sources Mechanical Signals Pheymatic Pheymatic Thermal Thermal Thermal Liquid SimDriveline SimHechanics 	Ideal Force Sensor Ideal Rotational Motion Sensor	Ideal Torque Sensor								

Figure 3.18: Mechanical Sensors Library



Figure 3.19: Block Diagram

- 20. Now you need to add the sources and scopes. They are found in the regular Simulink libraries. Open the Simulink > Sources library and copy the Signal Builder block into the model. Then open the Simulink > Sinks library and copy two Scope blocks. Rename one of the Scope blocks to *Velocity* and the other to *Position*.
- 21. Every time you connect a Simulink source or scope to a Simscape diagram, you have to use an appropriate converter block, to convert Simulink signals into physical signals and vice versa. Open the Simscape > Utilities library figure 3.20 and copy a Simulink-PS Converter block and two PS-Simulink Converter blocks into the model. Connect the blocks as shown in figure 3.20.
- **22.** Each topologically distinct physical network in a diagram requires exactly one Solver Configuration block, found in **the Simscape > Utilities library** figure 3.21. Copy this block into your model and connect it to the circuit by creating a branching point and connecting it to the only port of the Solver Configuration block. Your diagram now should look like figure 3.21.



Figure 3.7: Simscape Utilities Library



Figure 3.8: Block Diagram of System